

Dog Guard Installation Instructions

Parts List:

- 2 x Straight Tubes (Part A), equipped with extending legs
- 2 x Securing Knobs (Part B)
- 4 x Horizontal Tubes (Part C)
- 8 x Horizontal Tube Caps (Part D)
- 4 x U Shaped Tubes (Part E)
- 8 x Plastic Couplings (Part F)
- 4 x Rubber Feet (Part G)

Please check and identify the guard parts prior to assembly

Assembly:

1. Fit the plastic couplings (Part F) to the straight tubes (Part A).

Note: 4 couplings per tube

2. Slide the horizontal tubes (Part C) through the plastic couplings (Part F).
3. Fit the horizontal tube caps (Part D) to the end of the horizontal tubes (Part C).
4. Insert the U tubes (Part E) into the 4 horizontal tubes (Part C).
5. Fit the rubber feet (Part G) to the ends of the straight tubes (Part A).
6. Screw in the 2 securing knobs (Part B) onto the base end of the straight tubes (Part A).

Fitting to Vehicle:

- a) Place the assembled dog guard in the centre of the vehicle.
- b) Release the telescopic part of the straight tubes (Part A) so that the dog guard extends from floor to roof.
- c) Tighten the extended legs using the securing knobs (Part B).
- d) Twist feet on base of tubes until frame is tight.
- e) Fully extend the telescopic U tubes (Part E) by pulling out the sides until it meets the sides of the car.

