


PRODUCT MAP FOR - **RACK-ROCKER**

When assembling please place stickers, over leaf, on rack backing card for easy product identification & reorder.

	Column 1	Column 2	Column 3	Column 4	Column 5	Column 6	Column 7	Column 8
Row 1	410R - ROCKER SWITCH MINI ON/ OFF	411R - ROCKER SWITCH MINI AMBERON/ OFF	412R - ROCKER SWITCH MINI RED ON/OFF	413R - ROCKER SWITCH MINI GREENON/ OFF	411RD - ROCKER SWITCH AMBER DOT ON/ OFF	412RD - ROCKER SWITCH RED DOT ON/OFF	413RD - ROCKER SWITCH GREEN DOT ON/OFF	DL0594 - PUSH ON/OFF SWITCH
Row 2	0594A - AMBER ON/ OFF PUSH SWITCH WITH SPLASH PROOF COVER	0594G - GREEN ON/ OFF PUSH SWITCH WITH SPLASH PROOF COVER	0594B - BLUE ON/ OFF PUSH SWITCH WITH SPLASH PROOF COVER	0594R - RED ON/ OFF PUSH SWITCH WITH SPLASH PROOF COVER	0594BD - BLUE ILLUMI- NATED ON/ OFF PUSH SWITCH WITH SEAL	0594AD - AMBER ILLUMI- NATED ON/ OFF PUSH SWITCH WITH SEAL	DL0411 - AMBER MINI LED ROCKER SWITCH- [1]	DL0412 - RED MINI LED ROCK- ER SWITCH - [1]
Row 3	DL0413 - GREEN MINI LED ROCKER SWITCH- [1]	411MRA - AMBER ON/OFF ILLUMINAT- ED ROCKER SWITCH	411MRR - RED ON/ OFF ILLU- MINATED ROCKER SWITCH	415S - ROCKER SWITCH MINI ON/ OFF	410RSB - BLUE ON/ OFF ROCK- ER SWITCH	410RSG - GREEN ON/OFF ROCKER SWITCH	410RSR - RED ON/ OFF ROCK- ER SWITCH	411L - ROCKER SWITCH AMBER LED ON/OFF
Row 4	412L - ROCKER SWITCH RED LED ON/OFF	413L - ROCKER SWITCH GREEN LED ON/OFF	40R1 - MINI FLICK SWITCH ON/OFF	40R6 - MINI FLICK SWITCH ON/OFF AMBER	40R1 - MINI FLICK SWITCH ON/OFF	40R8 - MINI FLICK SWITCH ON/ OFF GREEN	40R9 - MINI FLICK SWITCH ON/ OFF BLUE	426 - MICRO TOGGLE SWITCH
Row 5	430W - WAT- ERPROOF COVER FOR METAL TOG	DL0420 - WARNING LIGHT - AM- BER FRONT BULB CHANGE- [1]	DL0421 - RED WARN- ING LIGHT FRONT BULB CHANGE- [1]	DL0422 - GREEN WARNING LIGHT FRONT BULB CHANGE- [1]	DL0423 - BLUE WARN- ING LIGHT FRONT BULB CHANGE- [1]	411W - AMBER LED WARNING LIGHT	412W - RED LED WARN- ING LIGHT	414W - BLUE LED WARNING LIGHT - [1]
Row 6	DL0414 - BLUE ON/OFF ILLUMINAT- ED ROCKER SWITCH	DL0415 - AMBER ON/OFF ILLUMINAT- ED ROCKER SWITCH	DL0416 - GREEN ON/OFF ILLUMINAT- ED ROCKER SWITCH	DL0417 - RED ON/ OFF ILLU- MINATED ROCKER SWITCH	433 - ROCK- ER SWITCH RED LED ON/OFF 20 AMP	433A - ROCKER SWITCH AMBER LED ON/OFF	500 - AUXILIARY LIGHTER PLUG - [5]	500J - AUX LIGHTER PLUG FITS JAP/EURO
Row 7								
Row 8	500L - AUXILIARY DELUXE LIGHTER PLUG LED WITH LEAD	595 - AUX PLUG SOCKET WITH COVER	595M - EXTRA AUXILIARY PLUG FOR 595	596P - CI- GAR LIGHT- ER PLUG - LARGE	596S - CIGAR LIGHTER SOCKET	596 - CIGAR LIGHTER - ILLUMI- NATED	597P - CI- GAR LIGHT- ER PLUG - SMALL	USB2 - BLACK DUAL USB CAR CHARGER QTY 1



410R 411R 412R 413R 411RD 412RD 413RD DL0594

0594A 0594G 0594B 0594R 0594BD 0594AD DL0411 DL0412

DL0413 411MRA 411MRR 415S 410RSB 410RSG 410RSR 411L

412L 413L 40R1 40R6 40R1 40R8 40R9 426

430W DL0420 DL0421 DL0422 DL0423 411W 412W 414W

DL0414 DL0415 DL0416 DL0417 433 433A 500 500J

500L 595 595M 596P 596S 596 597P USB2