

PRODUCT MAP FOR - **RACK-SWITCHES**

When assembling please place stickers, over leaf, on rack backing card for easy product identification & reorder.

	Column 1	Column 2	Column 3	Column 4	Column 5	Column 6	Column 7	Column 8
Row 1								
Row 2	401 - FLICK SWITCH ON/OFF - 20 AMP	402 - FLICK SWITCH ON/OFF/ ON 18 AMP - [5]	403 - FLICK SWITCH OFF/ON/ ON 25 AMP	404 - FLASHER SWITCH SHORT ARM - [5]	405 - FLASHER SWITCH LONG ARM	406 - FLICK SWITCH - AMBER	407 - FLICK SWITCH - RED	408 - FLICK SWITCH - GREEN
Row 3								
Row 4	409 - FLICK SWITCH - BLUE	430 - FLICK SWITCH ON/OFF 16 AMP - [5]	430M - FLICK SWITCH ON/OFF 25A METAL	592 - FLICK SWITCH ON/OFF/ ON H/D	401DBA - AMBER DUCK BILL TOGGLE SWITCH	401DBB - BLUE DUCK BILL TOGGLE SWITCH	401DBC - GREEN DUCK BILL TOGGLE SWITCH	401DBR - RED DUCK BILL TOGGLE SWITCH
Row 5								
Row 6	402M - FLICK SWITCH ON/OFF/ ON 25A METAL	404M - FLASHER SWITCH 25A METAL	428 - FLICK SWITCH RED LED 20A METAL - [5]	430M - FLICK SWITCH ON/OFF 25A METAL	428G - FLICK SWITCH GREEN LED 20A METAL	432M - FLICK SWITCH ON/ON METAL 25A - [5]	430CC - AIRCRAFT TYPE SWITCH COVER - RED	430CA - SWITCH COVER - CARBON
Row 7								
Row 8	430CG - AIR-CRAFT SWITCH COVER - GREEN	430CR - AIR-CRAFT SWITCH COVER - RED	430CY - AIRCRAFT SWITCH COVER - YELLOW	410 - ROCKER SWITCH ON/ OFF - [5]	411 - ROCKER SWITCH - AMBER - [5]	412 - ROCKER SWITCH - RED - [5]	413 - ROCKER SWITCH - GREEN - [5]	414 - ROCKER SWITCH - BLUE - [5]



401 402 403 404 405 406 407 408

409 430 430M 592 401DBA 401DBB 401DBG 401DBR

402M 404M 428 430M 428G 432M 430CC 430CA

430CG 430CR 430CY 410 411 412 413 414